Package Content

1×Laser Training Cartridge 2×Rubber Back Cap 9×Batteries


Specification
Wavelength:650nm
Tyoe:Visible Red Laser
Power:3mW
Battery:3×LR626
Offaxis Angle:0.1 mrad
Range for Sighting:5-100 yards
Dot Size:1 inches at 25 yards
Construction:Brass,gold-plated

Preparing The Friearm And Safety

- 1.Unload the Firearm.
- 2. Physically and visually inspect the chamter, bore and magazine to ensure that all ammunition has been removed.
- 3.Unload azzzmmunition from any magazines that will be used in training.
- 4. Store ammunition in an area that is separate from your training area.
- 5.Don't allow any live ammunition in the training area.

Warning: Firearms can cause serious injuries or death.


Using the Laser Cartridge



- 1.Unscrew the laser cartride and insert the battery pack (plus side facing up)into the laser-cartridge. Thread the action cap back onto thelaser module with the battery installed. Verify thethreading is fully closed.
- 2. Open the action slide and engage the


Warmning:Don't continue if slide is not held firmly or if slide is not good working order.

- 3. While pointing the barrel downward, insert the laser cartridge into the handgun by "dropping"it, laser side first, through the slide opening into the chamber. Push it gently into the chamber.
- 4. Enjoying your training.



Disassembly

- 1.Remove the magazine if it's in place.
- 2.Retract the action slide and engage the slide stop in the open position.
- 3. Make sure the actionslide is firmly held by the stop.



4.Take a wooden pencil with eraser or similar soft object and insert the pencil eraser side first,down the barrel from the front and gently push out thelaser cartridge from the chamber.

Application

Works with MantisX,LaserLyte,iTarget,G-Sight,LaserHit,and other visible laser simulators.