

---

## Magnetic Laser Boresighter

---



**Warning !**  
Avoid direct eye exposure  
Laser light . Keep away from  
children.

---

## USER MANUAL

---

- 1 Under normal operation it is safe to the humbaody caution: do not look into the path of the laser beam. direct eye contact with laser beam may cause eye injury!!
- 2 Power ON the laser beam in a safe direction, such as at a wall, ceiling or floor. Do not point laser beam at others
- 3 **Please Note:**  
Power ON the laser beam in a safe direction, such as at a wall, ceiling or floor. Do not point laser beam at others
- 4 **Please Note:**  
When fitting the Laser to an Air Rifle/Pistol, ensure it is in an unpressurised dry fire state. When using the Laser the Air Rifle/Pistol, confirm it's in the unpressurised state.
- 5 Always remove the Laser from the firearm after use. DO NOT forget to remove the Laser before the firearm is used again with LIVE ammunition.

### WARNING

The Laser Boresighter contains a laser emitter that will project a dot precisely along the bore line of your firearm to a target or reflective surface downrange. The Laser Boresighter is held against the muzzle of the firearm with a powerful magnet. The Boresighter can be used on any caliber firearm as long as the muzzle is clean, square, and free of any nicks or dings. Damage to the muzzle in the form of nicks or dings could affect the alignment of the laser with the bore line.

